



INSTRUCTIONS FOR USE

FOR PROFESSIONAL USE ONLY



Step 1

On the small bottle, remove the tamper band and pull the nozzle up.



Step 2

Cut the nozzle half way down its length, approximately where the dotted line is in the photograph.



Step 3

Remove the cap from the large bottle and then pour the contents of the small bottle into the large bottle.



Step 4

Replace the cap back on the large bottle and shake well for approximately 30 seconds. **DO NOT EXCEED MIXING TIME AS BOTTLE MAY RUPTURE.**



Step 5

Remove the cap and pour the Kongcrete evenly into the hole. The Kongcrete will expand and rise up and around the post and set hard in approximately 3 minutes, No weight, no water, no mess! Adjust the post for 30 seconds if necessary ensuring the post is in the middle of the hole.



Step 6

After full expansion, the Kongcrete will set hard in approximately 3 minutes reaching 100% of its strength after 2 hours. A hole can always be topped up with more composite if necessary after kits poured previously have completely expanded. After Kongcrete sets, any excess can be removed mechanically with a shovel, or by cutting with a utility knife.

